

Automatic Ball Drip

A58



► To drain low point of system between swing check valve and Fire Dept. connection. Automatically seals under pressure. Must be installed in vertical position only.

MALE x MALE

Standard equipment:
Cast brass straight connection male NPT both.

a	b
1/2"	1/2"
3/4"	3/4"

	1/2"	3/4"
A	2-11/16"	2-11/16"

